


BEFCO

Parts Manual

RS2


Finger Wheel Hay Rake

▶ Frame






RS2-02 AND RS2-03 FRAME



RS2-02 ARM



RS2-03 ARM



RS2-02 AND RS2-03 FRAME

ITEM #	PART #	DESCRIPTION	QTY.
1	503-268B	TOP HITCH PIN	1
2	503-269B	HAIR PIN COTTER	1
3	503-270B	A FRAME	1
4	007-4232	BOLT 14mm X 40mm	1
5	502-942B	FRAME 2 WHEEL	-
	503-271B	FRAME 3 WHEEL	-
6	503-271B	PIN	1
7	503-273B	HAIR PIN COTTER	1
8	503-274B	ARM COMPLETE W/ HUB 2 WHEEL	-
	503-275B	ARM COMPLETE W/ HUB 3 WHEEL	-
8A	503-276B	ARM WITHOUT HUB 2 WHEEL	-
	503-277B	ARM WITHOUT HUB 3 WHEEL	-
9	502-218B	DUST SEAL RING	-
10	502-219B	BEARING 30205	-
11	502-223B	HUB	-
12	502-221B	TINE CLIP	-
13	502-227B	OUTER WHEEL	-
14	502-226B	INNER WHEEL	-
15	502-224B	BEARING 30204	-
16	502-953B	NUT SELFLOCK	-
17	502-225B	DUST CAP	-
18	502-228B	TOOTH	-
19	502-220B	CARRAIGE BOLT 10mm X 25mm	-
20	009-0150	10mm HEX NUT	-
21	003-3176	BOLT 10mm X 25mm	-
22	000-1280	10mm LOCKWASHER	-
23	503-2783	STAND	-